
Sumitomo Drive Technologies

HYPONIC DRIVE®



《CAUTION》

- Gearmotors and reducers should be handled, installed, and maintained by trained technicians. Carefully read the instruction manual before use.
- ■A copy of this instruction manual should be sent to the actual user.
- ■This instruction manual should be retained by the user for future reference.

Safety and Other Precautions

- Carefully read this maintenance manual and all accompanying documents before use (installation, operation, maintenance, inspection, etc.). Thoroughly understand the machine, information about safety, and all precautions for correct operation. Retain this manual for future reference.
- Pay close attention to the "DANGER" and "CAUTION" warnings regarding safety and proper use.



: Improper handling may result in physical damage, serious personal injury and/or death.



: Improper handling may result in physical damage and/or personal injury.

Matters described in **CAUTION** may lead to serious danger depending on the situation. Be sure to observe important matters described herein.

! DANGER

- Transport, installation, plumbing, wiring, operation, maintenance, and inspections should be performed by trained technicians; otherwise, electric shock, personal injury, fire, or damage to the equipment may result.
- When using the equipment in conjunction with an explosion proof motor, a technician with electrical expertise should supervise the transport, installation, plumbing, wiring, operation, maintenance and inspection of the equipment so as to avoid a potentially nazardous situation that may result in electrical shock, fire, explosion, personal injury and/or damage to the equipment.
- When the unit is to be used in a system for human, transport a protective device should be installed to minimize chances of accidents that may result in personal injury, death, or damage to the equipment.
- When the unit is to be used for an elevator, install a protective device on the elevator side
 to prevent it from falling; otherwise, personal injury, death, or damage to the equipment
 may result.

How to Refer to the Maintenance Manual

• This maintenance manual is common for Hyponic drives, gearmotors with brake (Brake motors). The symbols shown below appear in the upper right corner of each page to indicate the classification. Read the applicable pages. On COMMON pages, these symbols identify distinctions between gearmotors and reducers.

Specifications	Common specifications	Gearmotor		
Specifications		Without Brake	With Brake(Brakemotors)	
Symbol	COMMON		ОВ	

----- CONTENTS -----

1. Inspection Upon Delivery
2. Storage
3. Transport
4. Installation
5. Coupling with Other Machines
6. Wiring
7. Operation
8. Daily Inspection and Maintenance
9. Brake Maintenance
10. Troubleshooting
11. Construction Drawings5
12. Warranty



1. Inspection Upon Delivery

! CAUTION

- Unpack the unit after verifying that it is positioned right side up; otherwise, injury may result.
- Verify that the unit received is in fact the one you ordered. Installing the wrong unit may result in personal injury or equipment damage.
- Do not remove the rating plate.

Verify the items listed below upon receiving the gearmotor. If a nonconformity or problem is found, contact our nearest agent, distributor, or sales office.


- (1) Does the information on the rating plate conform to what you ordered?
- (2) Was there any part broken during transport?
- (3) Are all bolts and nuts tightened firmly?

1-1) How to Refer to the Rating Plate

There are two types of nameplates, Type I and Type ${\rm I\hspace{-.07em}I}$. Some typical plates are shown below; refer to the proper one.

When making an inquiry, advise us of ① the type of gearmotor/spec code, ② reduction ratio, and ③ serial No.

(1) Nameplate Type I : Nameplate indicating for a reducer and a motor together



(2) Nameplate Type II: Individual nameplate indicating for a reducer and a motor separately




Fig. 1-b Nameplate of Gearmotor (Type II)

Note 1. Spec code is not necessarily indicated.

- 2. Nameplate of a motor is varied according to type of a motor.
- ${\tt 3.Motor\ meeting\ overseas\ standard\ is\ manufactured\ by\ Sumitomo\ Heavy\ Industries,\ Ltd.}$




1–2) Lubrication Method COMMON

All models of Hyponic drives, are grease-lubricated. They are grease-packed when shipped from our factory and arrive ready to operate.

1-3) Nomenclature of Gearmotor

Respective codes and Hyponic nomenclature are shown below. Please verify that the type of gearmotor you received conforms to what you ordered.






1-4) Spec cord of Gearmotor

Respective codes and motor nomenclature are shown below. Please verify that the gearmotor type you received conforms to what you ordered.


Notes : Because the spec cord is displayed when the customer directs it, it mighe not be writen in the rating plate and statemen of delivery.





1-5) Type of Motor

Respective codes and motor nomenclature are shown below. Please verify that the gearmotor type you received conforms to what you ordered.



1–6) Brake Type

The types of brake and the relationship between the motor capacity and brake delay time are as follows:

Table 1-1 Brake Type (15W-90W)

Brake type Frame size		Motor o	apacity	Brake delay time (sec)	
Brake type	3-phase motor		Single-phase motor	Normal braking action	Fast braking action
SB-004	01 03 05 07	15W 25W 40W 60W	15W 25W 40W	0.1-0.2	0.005-0.015
MB-003	17 1240	40W	40W	0.07-0.12	0.03-0.06
MB-005	15 17 1240	60W 90W	60W 90W	0.07-0.12	0.03-0.06

Table 1-2 Brake Type (0.1kW-11kW)

	asse : 2 State type (error)							
	Motor capacity				Brake delay time (sec)			
Brake type	3-phase motor	3-phase inverter motor	3-phase efficiency motor	cy phase motor Single-phase motor Single-phase motor Single-phase reversible motor		Normal braking action (Circuit for independent turn-off) 3-phase inverter motor	Fast braking action	
FB-01A1	0.1kW	-		0.1kW	0.15-0.2	- 0.015-0		
FB-02A1	0.2kW	0.1kW	_	0.2kW	0.15-0.2	0.08-0.12	0.015-0.02	
FB-05A1	0.25kW 0.4kW	0.2kW	0.2kW	_	0.1–0.15	0.03-0.07	0.01-0.015	
FB-1D	0.55kW 0.75kW	0.4kW	0.4kW	0.4kW	0.2-0.3	0.1-0.15		
FB-2D	1.1kW 1.5kW	0.75kW	0.75kW		0.2-0.3	0.1-0.15		
FB-3D	2.2kW	1.5kW	1.1kW 1.5kW		0.3-0.4	0.15-0.2	0.01-0.02	
FB-5B	3.0kW 3.7kW	2.2kW	2.2kW		0.4–0.5	0.2-0.25		
FB-8B	5.5kW	3.7kW	3.0kW 3.7kW	_	0.3-0.4	0.1-0.15		
FB-10B1	7.5kW	5.5kW	5.5kW		1.0-1.1	0.4-0.5	0.025-0.04	
FB-15B1	11kW	7.5kW	7.5kW		0.7-0.8	0.2-0.3	0.025-0.04	

Note: Type of a brake may not be shown in Table 1 according to the specification. Refer to a nameplate in such case.



2. Storage

When storing Hyponic drives for any extended period of time, consider the following important points:

2-1) Storage Location

Store the unit in a clean, dry place indoors.

· Avoid storage outdoors or in places with humidity, dust, sudden temperature changes or corrosive gas.

2-2) Storage Period

- (1) Storage period should be less than 1 year.
- (2) When the storage period exceeds 1 year, special rust prevention is necessary. Contact the factory for details.
- (3) Export models need export rust prevention. Contact the factory for details.

2-3) Use After Storage

- (1) Oil seals will deteriorate when exposed to high temperatures and UV rays. Inspect the oil seals before operation. Replace the oil seals after long-term storage if there is any sign of deterioration.
- (2) After starting the Hyponic drives or reducer, verify that there is no abnormal sound, vibration or heat built-up. If supplied as a brakemotor verify that the brake operates properly. If any anomaly is observed, contact our nearest agent, distributor or sales office.

3. Transport



DANGER

• Do not stand directly under a unit suspended by a crane or other lifting mechanism; otherwise, injury or death may result.

!\ CAUTION

- Exercise ample care so as not to drop the gearmotor or reducer. When a hanging bolt or hole is provided, be sure to use it. After mounting a cyclo unit to the equipment, do not hoist the entire machine using the hanging bolt or hole; otherwise, personal injury or damage to the equipment and/or lifting device may result.
- Before hoisting, refer to the rating plate, crate, outline drawing, catalog, etc. for the weight of the Hyponic drives or reducer. Never hoist a unit that exceeds the rating of the crane or other mechanism being used to lift it; otherwise, personal injury or damage to the equipment and/or lifting device may result.



4. Installation



DANGER

 Do not use a standard unit in an explosive atmosphere (which is likely to be filled with explosive gas or steam). Under such conditions, an explosion-proof motor should be used; otherwise, electric shock, personal injury, fire, explosion, or damage to the equipment may result.

CAUTION

- Do not use the cyclo gearmotor for purposes other than those shown on the rating plate or in the manufacturing specifications; otherwise, electric shock, personal injury, or damage to the equipment may result.
- Do not place flammable objects around the gearmotor; otherwise, fire may result.
- Do not place any object around the gearmotor; that will hinder ventilation; otherwise, excessive heat may build-up and cause burns or even fire.
- Do not step on or hang from the gearmotor; otherwise injury may result.
- Do not touch the shaft end of the gearmotor, inside keyways, or the edge of the motor cooling fan with bare hands; otherwise, injury may result.
- When the unit is used in food processing applications vulnerable to oil contamination, install an oil pan or other such device to cope with oil leakage due to failure or breakdown; otherwise, oil leakage may damage products.

4-1) Installation Location

Ambient temperature: -10°C to +40°C

Ambient humidity: 85% max

Ambient humidity: 85% max.

Altitude: 1000 m max.

Ambient atmosphere: There should be no corrosive gas, explosive gas, or steam.

The location should be well ventilated without dust.

Installation location: Indoors, with minimal dust and no water contact.

Water proof/Dust proof type

Note) IP65 is not available for underwater or high water pressured condition.

IP65: The IP indication that represents dust-proofing and water-proofing grades is prescribed by IEC529 and IEC34-5. "6" of IP65 represents a "perfect dust-proofing structure" that is the highest-grade protection from contact or entry of solids, while "5" represents protection from water, ensuring protection from water jets in all directions.

The motor has a structure that permits motor operation without any trouble even if it is exposed to water jets in all directions from a nozzle.

Test conditions: A nozzle of 6.3 mm in I.D. is placed at a distance of 3 m from the test piece and water jetted out of the nozzle under pressure of 30 kPa at the flow rate of 12.5 l/min is directed at the test piece in all directions for three minutes. After that, there should be no abnormality. The motor cannot be used underwater or in places exposed to high-pressure water jets.



- · Units made to special specifications are necessary for installation under conditions other than the above.
- · Units made according to the outdoor, explosion-proof or other specifications can be used under the specified conditions without any problem.
- · Install units where inspection, maintenance, and other such operations can be easily carried out.
- · Install units on a sufficiently rigid base.

4-2) Installation Angle

There is no restriction on the installation angle.

(For outdoor type gearmotors, standard installation angle is horizontal in the axial direction. Contact us for other axial directions.)

4-3) Flange mounting (RNFM series), Foot mounting (RNHM series)

Use bolt shown under Table 2. and refer to 5. coupling with other machines. (P14-18)

Table 2 Bolt Size

Series	Frame Size	Size of bolt
	01#, 03#	Hexagon socket head bolt M5
	05#, 07#, 15#, 17#, 190#	Hexagon socket head bolt M6
	20#, 23#, 25#, 270#, 1240#	Hexagon socket head bolt M8
RNFM	30#, 33#, 35#, 370#, 1340#	Hexagon socket head bolt M10
LINEIN	40#, 43#, 45#, 470#	Hexagon socket head bolt M10
	50#, 53#, 54#, 55#, 56#, 1440#	Hexagon socket head bolt M12
	1540#	Hexagon socket head bolt M16
	1630#, 1631#, 1640#	Hexagon socket head bolt M20
	20#, 23#, 25#, 190#, 270#	Bolt M8
RNHM	30#, 33#, 35#, 370#, 1340#	Bolt M10
	40#, 43#, 45#, 470#, 1440#	Bolt M12
	50#, 53#, 54#, 55#, 1540#	Bolt M16
	60#, 63#, 64#	Bolt M20

4-4) Hollow shaft (RNYM series)

There are (1) Torque arm mounting and (2) Flange and On-bed mounting for Hollow shaft.


(1) Torque arm mounting

(a-1) How to set the shaft (03#, 07#, 17#, 1010#)

Apply molybdenum disulfide grease to the surface of a driven shaft and the inner surface of a hollow shaft. Then insert the Drive into the driven shaft.


If the fitting is too tight, lightly knock the end face of a hollow output shaft with a wooden hammer for smooth insertion. Do avoid knocking the casing. We recommend making a jig shown Fig 2. Using this jig, you can insert the Drive smoothly.





The hollow shaft is made according to the tolerances of JIS H8. If you experience impact or notice a large radial load with the hollow shaft, further tighten the fitting between the hollow shaft and the driven shaft. (We recommend JIS js6 or k6 as the tolerance of a driven shaft.)

(b-1) Method to avoid the Drive from slipping away from a driven machine. (Fig.3–5) (03#, 07#, 17#, 1010#)



Method to avoid the Drive from slipping reactor to a driven machine. (Fig.6–7)




Fig.6 Fixed by spacer

Fig.7 Fixed by set screw




(c-1) How to set a torque arm (03#, 07#, 17#, 1010#)


Mount a torque arm on the driven machine side of the Drive casing. Use hexagon socket head bolts for mounting. (See Table 3 for bolt sizes.)

Torque arm anti-rotation stopper should be designed so as to allow movement of the torque arm to make sure that the contact surface between the Drive and shaft are free from excess force.

Don't fix the torque arm by anti-rotation bolts.

For such applications as requiring frequent start and stop or frequent reversing of the rotating direction, insert a rubber bushing between the torque arm and securing bolt (or spacer) in order to relax impact load.





(Adjust the allowance according to the movement of the machine.)

(Excessive force on the whirl stop bolt. machine, and Hyponic may cause damage.)

Good example






Fig.8 A-part securing methods

Table 3 Size of hexagon socket head bolt

Frame size	Bolt
03#	M5
07#, 17#, 1010#	M6

(d-1) How to remove the shaft (03#, 07#, 17#, 1010#)


Make sure that excess force does not act on Drive and shaft.



(a-2) How to set the shaft (1110#-1640#)

Apply molybdenum disulfide grease to the surface of a driven shaft and the inner surface of a hollow shaft. Then insert the Drive into the driven shaft.

If the fitting is too tight, lightly knock the end face of a hollow output shaft with a wooden hammer for smooth insertion. Do avoid knocking the casing. We recommend making a jig shown Fig 9. Using this jig, you can insert the Drive smoothly.



The hollow shaft is made according to the tolerances of JIS H8. If you experience impact or notice a large radial load with the hollow shaft, further tighten the fitting between the hollow shaft and the driven shaft, (We recommend JIS js6 or k6 as the tolerance of a driven shaft.)

(b-2) Method to avoid the Drive from slipping away from a driven machine. (Fig.10-12) (1110#-1640#)




Fig.10 Fixed by spacer and plate

Fig.11 Fixed by end plate

Fig.12 Fixed by set screw and stopper ring



Method to avoid the drive from slipping reactor to a driven machine (Fig.13–15)




Fig.13 Fixed by stopping shaft

Fig.14 Fixed by spacer

Fig.15 Fixed by set screw


(c-2) How to set a torque arm (1110#-1640#)

Mount a torque arm on the driven machine side of the Drive casing. Use hexagon socket head bolts for mounting. (See Table 4 for bolt sizes.)

Torque arm anti-rotation stopper should be designed so as to allow movement of the torque arm to make sure that the contact surface between the Drive and shaft are free from excess force.


Don't fix the torque arm by anti-rotation bolts.

For such applications as requiring frequent start and stop or frequent reversing of the rotating direction, insert a rubber bushing between the torque arm and securing bolt (or spacer) in order to relax impact load.



(Adjust the allowance according to the movement of the machine.)

(Excessive force on the whirl stop bolt. machine, and Hyponic may cause damage.)



Good example

Bad example

Fig.16 A-part securing methods




Table 4 Size of hexagon socket head bolt

Frame size	Bolt
1110#, 1120#	M6
1210#, 1220#, 1230#, 1240#	M8
1310#, 1320#, 1330#, 1340#, 1410#, 1510#	M10
1420#, 1430#, 1440#, 1520#, 1521#, 1522#, 1634#	M12
1530#, 1531#, 1540#	M16
1630#, 1631#, 1632#, 1633#, 1640#	M20

(d-2) How to remove the shaft (1110#-1640#)

Make sure that excess force does not act on the Drive and shaft. Using a jig as shown in Fig. 17 will facilitate removal of the shaft.


Parts for setting, securing or removing the shaft should be prepared by the user.




f......Spacer h......Plate

(2) Flange and On-bed mounting (Standard)

When installing the Drive, pay attention to the alignment between the Drive and shaft to be driven so that the Drive is free from excess force.



(The concentricity between the \square shaft and spigot joint is out of \square allowable range.)



(The shaft centerline is not□ positioned at right angles to the□ flange.)

Bad example

Bad example

Fig.18 Flange coupling



5. Coupling with Other Machines

! CAUTION

- Confirm the rotation direction before coupling the unit with the driven machine. Incorrect rotation direction may cause personal injury or damage to the equipment.
- When operating the gearmotor alone (uncoupled), remove the key that is temporarily attached to the output shaft; otherwise, personal injury may result.
- Cover the rotating parts; otherwise, personal injury may result.
- When coupling the gearmotor with a load, check that the centering, the belt tension and parallelism of the pulleys are within the specified limits. When the unit is directly coupled with another machine, check that the direct coupling accuracy is within the specified limits. When a belt is used for coupling the unit with another machine, check the belt tension. Correctly tighten bolts on the pulley and coupling before operation; otherwise, personal injury may result because of misalignment.



5-1) Confirming Rotation Direction

Figure 19–21 shows the rotation direction of the output shaft when wires are connected as shown in Fig. 28–32 on page24–34.

Fig.19 Rotation direction of slow speed shaft (RNYM Series)

Frame size	Reduct	ion ratio
03#,07#	5, 80, 100, 120, 160, 200, 240	7.5, 10, 12, 15, 20, 25, 30, 40, 50, 60
17#	5, 7.5, 10, 12, 80, 100, 120, 150, 200, 240	15, 20, 25, 30, 40, 50, 60
1010#,1110#,1210#		5,7,10
1310#,1410#,1510#	_	5,7,10
1120#,1220#,1320#	5, 7, 10, 12, 15, 20, 25, 30, 40, 50, 60	
1420#,1520#	5, 7, 10, 12, 15, 20, 25, 30, 40, 50, 60	_
1521#	5, 7, 10, 12, 15, 20, 25	_
1522#	5, 7, 10, 12, 15	_
1230#,1330#		80, 100, 120, 150, 200, 240
1430#,1530#	_	80, 100, 120, 130, 200, 240
1531#	_	40, 50, 60, 80
1630#	_	80, 100, 120
1631#	_	150, 200, 240
1632#	30	40, 50
1633#	20, 25	30, 40
1634#	5, 7, 10, 12, 15	20, 25
1240#,1340#,1440#	300, 360, 480, 600, 720, 900, 1200, 1440	
1540#,1640#	300, 360, 460, 600, 720, 900, 1200, 1440	_
Rotation direction		

[·] Change over the SW shown in Fig.29, 32 to reverse the rotation of 15-90W Single-phase motor, Single-phase reversible motor.

[·] Change the positions of R and T shown in Fig.28, 30 to reverse the rotation of 3-phase motor, 3-phase high efficiency motor.

5. Coupling with Other Machines



Fig.20 Rotation direction of slow speed shaft (RNFM Series)

Frame size	Reducti	ion ratio		
01#,03#,05#,07#	5, 80, 100, 120, 160, 200, 240	7.5, 10, 12, 15, 20, 25, 30, 40, 50, 60		
15#,17#	5, 7.5, 10, 12, 80, 100, 120, 150, 200, 240	15, 20, 25, 30, 40, 50, 60		
190#	5	7.5, 10, 15, 20, 30, 40, 50, 60		
20#	10, 15, 20, 25, 30, 40, 50, 60	80, 100, 120		
23#	10, 15, 20, 25, 30	40, 50, 60		
25#	_	150, 200, 240		
270#	5, 7.5, 10, 15, 20	30		
30#	_	80, 100, 120		
33#	10, 15, 20, 25, 30	40, 50, 60		
35#	_	150, 200, 240		
370#	5, 7.5, 10, 15, 20	30		
40#	_	80, 100, 120		
43#	10, 15, 20, 25, 30	40, 50, 60		
45#	_	150, 200, 240		
470#	5, 7.5, 10, 15, 20	30		
50#	_	80, 100, 120		
53#,54#	10, 15, 20, 30	40, 50, 60, 80		
55#	_	150, 200, 240		
1630#	_	80, 100, 120		
1631#	_	150, 200, 240		
1240#,1340#,1440#	300, 360, 480, 600, 720, 900, 1200, 1440	_		
1540#,1640#	300, 300, 400, 000, 720, 900, 1200, 1440			
Rotation direction				
	R Type L Type	R Type L Type		

 $[\]cdot$ Change over the SW shown in Fig.29, 32 to reverse the rotation of 15-90W Single-phase motor, Single-phase reversible motor .

[·] Change the positions of R and T shown in Fig.28, 30 to reverse the rotation of 3-phase motor, 3-phase high efficiency motor.

5. Coupling with Other Machines



Fig.21 Rotation direction of slow speed shaft (RNHM Series)

Frame size	Reduction ratio				
190#	7.5, 10, 15, 20, 30, 40, 50, 60	5			
20#	10, 15, 20, 25, 30, 40, 50, 60	80, 100, 120			
23#	10, 15, 20, 25, 30	40, 50, 60			
25#	_	150, 200, 240			
270#	5, 7.5, 10, 15, 20	30			
30#	_	80, 100, 120			
33#	10, 15, 20, 25, 30	40, 50, 60			
35#	_	150, 200, 240			
370#	5, 7.5, 10, 15, 20	30			
40#	_	80, 100, 120			
43#	10, 12, 15, 20, 25, 30	40, 50, 60			
45#	_	150, 200, 240			
470#	5, 7.5, 10, 15, 20	30			
50#	_	80, 100, 120			
53#,54#	10, 15, 20, 30	40, 50, 60, 80			
55#	_	150, 200, 240			
60#	_	80, 100, 120			
63#	10, 15, 20, 30	40, 50			
64#	10, 15, 20	30, 40			
1340#,1440#,1540#	_	300, 360, 480, 600, 720, 900, 1200, 1440			
Rotation direction	R Type L Type T Type	R Type L Type T Type			

 $[\]cdot$ Change over the SW shown in Fig.29, 32 to reverse the rotation of 15-90W Single-phase motor, Single-phase reversible motor.

[·] Change the positions of R and T shown in Fig.28, 30 to reverse the rotation of 3-phase motor, 3-phase high efficiency motor .



5-2) Coupling Installation

- · When installing a coupling, do not impact or apply excessive thrust load to the shaft; otherwise, the bearing may be damaged.
- · Thermal shrinking or end cap screws are recommended for mounting (Fig.22).



(1) When using a Coupling

The accuracy of the dimensions (A,B,and X) shown in Fig.23 should be within the toleronce shown in Table 5.



Fig.22




Fig.23

Table 5 Centering accuracy of flexible coupling A Dimension 0.1mm or manufacturer's Tolerance specification **B** Dimension 0.1mm or manufacturer's Tolerance specification manufacturer's X dimension specification

(2) When using a Chain Sprocket and Gear

- · The chain tension angle should be perpendicular to the shaft.
- · Refer to the chain catalog for the chain tension.
- · Select sprockets and gears whose pitch diameter are three times the shaft diameter or greater.
- · Install sprocket and gears so that their point of load application will be closer to the gearmotor side with respect to the length of the shaft. (Fig.24)

(3) When using a V-belt

- · Excessive V-belt tension will damage the shaft and bearing. Refer to the V-belt catalog for proper tension.
- · The parallelism and eccentricity (B) between two pulleys should be within 20'. (Fig25)
- · Use a matched set with the same circumferential length when more than one belt is to be installed.




Fig.24



Fig.25



6. Wiring

■ Wiring for SUMITOMO standard motor is shown below. Refer to the respective instruction manual when using another manufacturer,s motor.

M DANGER

- Do not handle the unit when cables are live. Be sure to turn off the power; otherwise, electric shock may result.
- Connect a power cable to the unit according to the connection diagram shown inside the terminal box or in the maintenance manual; otherwise, electric shock or fire may result.
- Do not forcibly curve, pull, or clamp the power cable and lead wires; otherwise, electric shock or fire may result.
- Correctly ground the grounding bolt; otherwise, electric shock may result.
- The lead-in condition of an explosion-proof type motor shall conform to the facility's electrical codes extension regulations, and explosion-proofing guide, as well as the maintenance manual; otherwise, explosion, electric shock, personal injury, fire or damage to the equipment may result.
- Do not wet by water for electrical parts like cable connector, rectifier or capacitor, even for water-proof type.




CAUTION

- When wiring, follow the facility's electrical codes and extension regulations; otherwise, burning, electric shock, injury, or fire may result.
- The motor is not equipped with a protective device. However, it is compulsory to install an overload protector according to facility electrical codes. It is recommended to install other protective devices (earth leakage breaker, etc.), in addition to an overload protector, in order to prevent burning, electric shock, personal injury, and fire.
- Connecting method is shown below. Insulats the connecting point using insulating tape.



- Never touch the terminals when measuring insulation resistance; otherwise, electric shock may result.
- When measuring the insulation resistance of an explosion-proof type motor, confirm that there is no gas, steam, or other explosive substance in the vicinity, in order to prevent possible explosion or ignition.
- When using a 400V-class inverter to drive the motor, mount a suppresser filter or reactor on the inverter side, or provide reinforced insulation on the motor side; otherwise, dielectric breakdown may couse fire or damage to the equipment.
- For brakemotors, install a rectifier in a place where the temperature is 60°C or below; if the ambient temperarure exceeds 60°C, be sure to use a cover for protection.
- For single-phase motors, exercise care so as not to mistake the starting capacitor for the operation capacitor. The starting capacitor if will be broken used for operation.
- For single-phase motors, exercise care so as not to damage the vinyl cover of the starting capacitor, otherwise electric shock may result.
- Do not open water-proof dust-proof box for water-proof type, other wise electrical shock, fire or damage to the equipment, may result.

Fig.26



 For brake motors, do not electrify a brake coil continuously when a motor is stopping; otherwise, a brake coil may burn and fire may result.




- Long cables cause voltage to drop. Select cables with appropriate diameter so that the voltage drop will be less than 2%.
- After wiring outdoor and explosion-proof type motors, check that terminal box mounting bolts are not loose, and correctly attach the terminal box cover.

6-1) Attaching/Detaching The Terminal Box Cover

(1) Detaching

As shown in Fig. 27, hold both sides of the terminal box and pull it towards you. The cover will detach.



(2) Attaching Fig.27

Press the terminal box cover to the terminal box case until it snaps into place.

6-2) Measuring Insulation Resistance

· When measuring the insulation resistance, disconnect the motor from the control panel. Check the motor separately.

Measure the insulation resistance before wiring. The insulation resistance (R) varies according to the motor output, voltage, type of insulation, coil temperature, humidity, dirt, period of operation, test electrification time, etc. Usually, the insulation resistance exceeds the values shown in Table 6.

Table 6 Insulation resistance

Megohmmeter voltage	Insulation resistance (R)	
500V	$1M(\Omega)$ or more	

Reference: The following equations are shown in JEC-2100.

R (> or =)
$$\frac{\text{Rated voltaga (V)}}{\text{Rated output (kW)} + 1000}$$
 (M\O)

R (> or =)
$$\frac{\text{Rated voltaga (V) + Speed (rpm)/3}}{\text{Rated output (kW) + 2000}} + 0.5 \text{ (M}\Omega)$$

A drop in insulation resistance may be attributed to poor insulation. In that case, do not turn on the power. Contact our nearest agent, distributor, or sales office.



6-3) Protection Coordination

- (1) Use a molded case circuit breaker for protection against short circuit.
- (2) Use an overload protection device that protects the unit against asurge of electric current exceeding that shown on the rating plate.
- (3) For an explosion-proof type motor, use an overload protector that can protect the unit within the allowable binding hour by means of the locked rotor current shown on the rating plate.

6-4) Single-phase motor, Single-phase reversible motor Specification

Table 7 15-90W Single-phase motor Capacitor Specification

Motor voltage	Capacitor voltage ressistance	Motor type	Motor capacity (W)	Frame size	Capacitor capacity (μ F)
			15	01#, 03#	5
			25	01#, 03#	7
		Induction	40	05#, 07#	12
		induction	40	17#, 1240#	14
			60	17#, 1240#	18
100V	220V		90	15#, 17#, 1240#	25
1007	2200	Reversible	15	01#, 03#	6
			25	01#, 03#	10
			40	05#, 07#	14
			40	17#, 1240#	16
			60	17#, 1240#	22
			90	15#, 17#, 1240#	32
		Induction	40	17#, 1240#	3.5
			60	17#, 1240#	4.5
2001/	440V		90	15#, 17#, 1240#	6.5
200V	440V		40	17#, 1240#	4
		Reversible	60	17#, 1240#	5.5
			90	15#, 17#, 1240#	8

Table 8 0.1-0.4kW Capacitor start and run type Single phase motor Capacitor Specification

Malan	Motor	For starting		For operation	
Motor voltage	capacity (W)	Capacitor capacity(μ F)	Capacitor voltage resistance (V)	Capacitor capacity(μ F)	Capacitor voltage resistance (V)
	0.1	60	125	10	230
100V/200V	0.2	100	125	30	230
	0.4	200	125	40	230



6-5) Motor (without brake) Connection

Fig.28 shows the 3-phase motor, 3-phase high efficiency motor, 3-phase inverter motor (without brake) connection and the standard specifications for terminal codes.

Fig.28-a In a case of three lead wires





Fig.28-b In a case of six lead wires



MC: Electromagnetic contactor

OLR: Overload relay or thermal relay

VR: Varistor (protector element)

These should be furnished by the customer.

· This drawing shows for a motor based on standard specification for domestic market. Motor based on overseas standard shall be referred to us.


· Refer to connection diagram on the motor when sharing power supply.

C: Capacitor -



Fig.29 shows the Single-phase motor, Single-phase reversible motor (without brake) connection and the standard specifications.

Fig.29-a In a case of capacitor run type 15W-90W




- For 15W–90W capacitor run type , connect the accessory capacitor. (See Table 7 on page 23 for the capacitor.)
- · Do not open water-proof dust-proof box for water-proof type , otherwise electrical shock, fire or damage to the equipment may result.
- · A capacitor is not water-proofed for water-proof type .

Accessory

• This drawing shows for a motor based on standard specification for domestic market. Motor based on overseas standard shall be referred to us.



Fig.29-b In a case of capacitor start and capacitor-run type 0.1kW-0.4kW




- MC: Electromagnetic contactor
 OLR: Overload relay or thermal relay
 Rotation shifting switch
 These should be furnished by the customer.
- · Connection to Z1 and Z2 shall be exchanged with each other when reverse rotation is necessary if the motor is provided only for rotation in one direction.
- · A capacitor is built in the terminal box of capacitor start and capacitor-run type 0.1kW-0.4kW.
- · Do not open water-proof dust-proof box for water-proof type , otherwise electrical shock, fire or damage to the equipment may result.
- · A capacitor is not water-proofed for water-proof type .
- This drawing shows for a motor based on standard specification for domestic market.
 Motor based on overseas standard shall be referred to us.



6-6) Motor with brake Connection

Fig.30 shows the 3-phase motor, 3-phase high efficiency motor with brake connection and the standard specifications for terminal codes.

Fig.30-a For operating in one directions (In a case of three lead wires)



- Note 1: A rectifier is supplied separately for SB-004.
- Note 2: A rectifier is built in the brake of motors for MB-003-MB005. (A rectifier is supplied separately for water-proof type.)
- Note 3: Do not open water-proof dust-proof box for water-proof type, otherwise electrical shock, fire or damage to the equipment may result.
- Note 4: A rectifier is not water-proofed for water-proof type.
- MC : Electromagnetic contactor
- OLR : Overload relay or
 - thermal relay
 'R : Varistor (Protector element)
- These should be furnished by the customer.

Varistor (VR) Capacity

Input	power	AC200V-230V	AC380V-460V
Rated	voltage of varistor	AC260V-300V	AC510V
Voltag	ge of varistor	430V-470V	820V
oower	SB-004, FB-01A1, 02A1, 05A1	0.25Watt or more	0.4Watt or more
_ 0	FB-1D	0.4Watt or more	0.6Watt or more
Rated of vari	FB-2D, 3D, 5B, 8B	0.6Watt or more	1.0Watt or more
	FB-10B1,15B1	1.0Watt or more	1.0Watt or more


Varistor is optionally available at Sumitomo.

- Use fast braking action for lifting devices or for better stopping accuracy.
- DC braking capacity (for DC coil loading) exceeding 5 times the braking current shown on the name plate is recommended for the fast braking action.

- Refer to page 6 table 1-1, 1-2 for brake type.
- This drawing shows for a motor based on standard specification for domestic market. Motor based on overseas standard shall be referred to us.
- Refer to connection diagram on the motor when sharing power supply.



Fig.30-b For operating in one directions (In a case of six lead wires)



- · Refer to page 6 table 1-2 for brake type.
- This drawing shows for a motor based on standard specification for domestic market. Motor based on overseas standard shall be referred to us.
- · Refer to connection diagram on the motor when sharing power supply.

MC : Electromagnetic contactor
OLR: Overload relay or thermal relay
VR : Varistor (Protector element)

These should be furnished by the customer.

Varistor (VR) Capacity

	. , .	-	
Input power		AC200V-230V	AC380V-460V
Rate	d voltage of varistor	oltage of varistor AC260V-300V	
Volta	ge of varistor	430V-470V	820V
Rated power of varistor	FB-15B1	1.0Watt or more	1.0Watt or more

Varistor is optionally available at Sumitomo.

- Use fast braking action for lifting devices or for better stopping accuracy.
- DC braking capacity (for DC coil loading) exceeding 5 times the braking current shown on the name plate is recommended for the fast braking action.



Brake type: SB-004 Brake type : MB-003-005 Nomal braking action Control panel Control panel OLR OLR ě ŏ Ferminal Terminal Red White Black Motor Brake Motor Rectifier Fast braking action Control panel Control panel OLR Ferminal box **Terminal box** Red White Blac Yellov Yellov Red White Black Motor Brake Brake type: Brake type: FB-1D-15B1 FB-01A1-05A1 Nomal braking action Control panel Control panel OLR OLR **Terminal box** erminal box Motor

Fig.30-c For operating in both directions (In a case of three lead wires)

Note 1: A rectifier is supplied separately for SB-004.

Note 2: A rectifier is built in the brake of motors for MB-003-MB005. (A rectifier is supplied separately for water-proof type.)

Note 3: Do not open water-proof dust-proof box for water-proof type, otherwise electrical shock, fire or damage to the equipment may result.

Note 4: Rectifier, capacitor are not waterproofed for water-proof type.

Rotation shifting switch
OLR: Overload relay or thermal relay
VR: Varistor (Protector element)

These should be furnished by the customer.

Varistor (VR) Capacity

Input power		AC200V-230V	AC380V-460V
Rated voltage of varistor		voltage of varistor AC260V-300V	
Voltaç	ge of varistor	430V-470V	820V
ower tor	SB-004, FB-01A1, 02A1, 05A1	0.25Watt or more	0.4Watt or more
	FB-1D	0.4Watt or more	0.6Watt or more
Rated of varit	FB-2D, 3D, 5B, 8B	0.6Watt or more	1.0Watt or more
	FB-10B1,15B1	1.0Watt or more	1.0Watt or more

Varistor is optionally available at Sumitomo.

- Use fast braking action for lifting devices or for better stopping accuracy.
- DC braking capacity (for DC coil loading) exceeding 5 times the braking current shown on the name plate is recommended for the fast braking action.
- · Refer to page 6 table 1-1, 1-2 for brake type.

Control panel

ŏ

erminal

OLR

Fast braking action

Forward

OLR

Motor

 This drawing shows for a motor based on standard specification for domestic market. Motor based on overseas standard shall be referred to us.

Rectifier

Control panel

ŏ


Terminal

· Refer to connection diagram on the motor when sharing power supply.

Motor



Fig.30-d For operating in both directions (In a case of six lead wires)



- · Refer to page 6 table 1-2 for brake type.
- · This drawing shows for a motor based on standard specification for domestic market. Motor based on overseas standard shall be referred to us.
- · Refer to connection diagram on the motor when sharing power supply.

Rotation shifting switch
MC : Electromagnetic contactor
OLR : Overload relay or thermal relay
VR : Varistor (Protector element)

These should be furnished by the customer.

Varistor (VR) Capacity

Input power		AC200V-230V	AC380V-460V
Rated voltage of varistor		AC260V-300V	AC510V
Voltage of varistor		430V-470V	820V
Rated power of varistor	FB-15B1	1.0Watt or more	1.0Watt or more

Varistor is optionally available at Sumitomo.

- Use fast braking action for lifting devices or for better stopping accuracy.
- DC braking capacity (for DC coil loading) exceeding 5 times the braking current shown on the name plate is recommended for the fast braking action.



Fig.31 shows the Inverter motor with brake connection and the standard specifications for terminal codes.

Fig.31-a For inverter driven (In a case of three lead wires)





Fig.31-b For inverter driven (In a case of six lead wires)




- · Refer to page 6 table 1-2 for brake type.
- · For Three-Phase Motors and Three-Phase High Efficiency Motor to be driven by Inverters, please refer to the wiring diagram for inverter motor.
- · Insulation suitable for a motor is necessary in inverter drive with 3-phase 400V motor or 3-phase 400V high efficiency motor.
- · Inverter can not be applied to MB brake type (excl. water-proof type) due to a built-in rectifier into brake.
- This drawing shows for a motor based on standard specification for domestic market. Motor based on overseas standard shall be referred to us.
- · Refer to connection diagram on the motor when sharing power supply.



Fig.32 shows the Single-phase motor with brake connection and the standard specifications.

Fig.32-a-1 For operating in one directions (In a case of capacitor run type 15W-90W)



- · Refer to page 6 table 1-1 for brake type.
- This drawing shows for a motor based on standard specification for domestic market. Motor based on overseas standard shall be referred to us.



Brake type: FB-01A1-02A1 100V 200V Nomal braking action Control panel Control panel MC МС OLR OLR χoq ğ erminal erminal δU₁ ٥٧ ٥٧ ٥Z 1 2 4 M N Brake Rectifier Brake Rectifier Motor Fast braking action Control panel Control panel MC MC OLR OLR erminal box ŏ 0U1 0U2 0Z1 erminal-M N δU₁ Rectifier Brake Brake Rectifier Brake type: FB-1D 100V 200V Note: Connection to Z1 and Z2 shall be exchanged with each other when reverse rotation is necessary if the motor Nomal braking action Control panel Control panel is provided only for rotation in one МС MC direction. OLR OLR MC : Electromagnetic contactor χoq These should be ŏ OLR: Overload relay or furnished by the **Terminal Terminal** δU₁ 2 3 4 thermal relay 2 3 4 customer. U₂ O Z₁ O Motor : Varistor (Protector Brake Rectifier U2 Z1 Brake Rectifier element) ۱۵۰۰۰۱ Motoi Varistor (VR) Capacity AC100V. 200V Input power Rated voltage of varistor AC260V-300V Voltage of varistor 430V-470V braking action panel panel MC FB-01A1, 02A1 0.25Watt or more Rated power MC of varistor FB-1D 0.4Watt or more Control Control OLR OLR Varistor is optionally available at Sumitomo. Terminal box Terminal box · Use fast braking action for lifting devices or Fast for better stopping accuracy. βU M N DC braking capacity (for DC coil loading) Rectifier Brake U2 Z1 Brake Rectifier exceeding 5 times the braking current shown Motor Motor on the name plate is recommended for the fast braking action.

Fig.32-a-2 For operating in one directions (In a case of capacitor start and capacitor-run type 0.1kW-0.4kW)


- · Refer to page 6 table 1-2 for brake type.
- This drawing shows for a motor based on standard specification for domestic market. Motor based on overseas standard shall be referred to us.

Fig.32-b-1 For operating in both directions (In a case of capacitor start and capacitor-run type 0.1kW-0.4kW)

200V

Brake type: FB-01A1-02A1

100V



· This drawing shows for a motor based on standard specification for domestic market. Motor based on overseas standard shall be referred to us.



Table 9 Varistor (VR) Capacity

Input power			AC200V-230V	AC380V-460V
Rated voltage of varistor			AC260V-AC300V	AC510V
Voltage of varistor			430V-470V	820V
Rated power of varistor	Brake type	SB-004, FB-01A1, 02A1, 05A1	0.25Watt or more	0.4Watt or more
		FB-1D	0.4Watt or more	0.6Watt or more
		FB-2D, 3D, 5B, 8B	0.6Watt or more	1.0Watt or more
		FB-10B1, 15B1	1.0Watt or more	1.0Watt or more

- The brake delay time of the normal braking action is different from that of the fast braking action. Table 1 on page 6 shows the delay time. Use a circuit that meets your requirements.
- DC braking capacity (for DC coil loading) exceeding 5 times the braking current shown on the name plate is recommended for the fast braking action.
 - · Use fast braking action for lifting devices or for better stopping accuracy.
 - · Use fast braking action when a leading capacitor is used.
- For 15W–90W single-phase capacitor run type motor, connect the accessory capacitor, (see Table 7 on page 23 for the capacitor.)
- · Pay attention to the following items when driving an inverter .
 - For the inverter-driven motor with a brake, use the primary-side power supply for braking as shown in Fig.31, and synchronize the braking operation with the ON/OFF operation of the unit.
 - For the inverter-driven motor with a brake, interlocking with the inverter is necessary to engage/release the MC. Refer to the inverter maintenance manual or guide.
 - · During the low speed running, the mechanical life might be in danger of being shortened by reducing the cooling ability.
 - · When it happens, please reduce the time that brake's power is on.



7. Operation

MANGER

- Do not approach or touch rotating parts (output shaft, etc.) during operation; loose clothing may become caught in these rotating parts and cause serious injury or death.
- When the power supply is interrupted, be sure to turn off the power switch. Unexpected resumption of power may cause electric shock, personal injury, or damage to the equipment.
- Do not operate the unit with the terminal box cover removed. Return the terminal box cover to the original position after maintenance in order to electric shock.
- Do not open the terminal box cover when power is supplied to an explosion-proof type motor prevent otherwise, explosion, ignition, electric shock, personal injury, fire, or damage to the equipment may result.
- For motors equipped with brakes, do not operate with brakes released by the manual loosening bolt, otherwise the motor may fall or go out of control.
- Do not use of <u>single-phase motor</u> if there is possibility of loaded more than motor rated torque, otherwise the motor may go out of control.

! CAUTION

- Do not put fingers or foreign objects into the opening of the gearmotor otherwise electric shock, personal injury, fire, or damage to the equipment may result.
- The gearmotor becomes very hot during operation. Do not touch or come in contact with the unit; otherwise, burns may result.
- If any abnormality occurs during operation, stop operation immediately; otherwise, electric shock, personal injury, or fire may result.
- Do not operate the unit in excess of the rating; otherwise, personal injury or damage to the equipment may result.
- Do not touch the charging portion of the starting capacitor of a single-phase motor until the capacitor has discharged completely, otherwise electric shock may result.
- When reversing the rotation of a single-phase motor other than a reversible motor, be sure to stop the motor before reversing the rotation, otherwise the rotation may not be successfully reversed, and the motor may go out of control.

After the unit is installed and properly wired, check the following before operating.

- (1) Is the wiring correct?
- (2) Is the unit properly coupled with the driven?
- (3) Are foundation bolts tightened firmly?
- (4) Is the direction of rotation as required?

After confirming these items, conduct initial break-in without a load; then gradually apply a load. Check the items shown in Table 10 on page 37.



Table 10 Items to check during initial start - up and break - in period

Is abnormal sound or vibration generated ?	 (1) Is the housing deformed because the installation surface is not flat? (2) Is insufficient rigidity of the installation base generating excessive noise? (3) Is the shaft center aligned with the driven machine? (4) Is the vibration of the driven machine transmitted to the gearmotor?
Is the surface temperature of the gearmotor or reducer abnormally high ?	(1) Is the voltage rise or drop substantial? (2) Is the ambient temperature too high? (3) Does the current flowing to the gearmotor exceed the rated current shown on the rating plate?

- \cdot If any abnormality is found, stop operation and contact our nearest agent, distributor, or sales office.
- · In the initial operation or right after exchange of the brake lining, specified braking torque might not be outputted. When this happens, under the least loading, turn the power switch on and off to rub the friction sides together.
- · Because of the brake structure, rubbing noise of the lining might be made, which has no problems with the performance.



8. Daily Inspection and Maintenance

Λ

DANGER

- Do not handle the unit when cables are live. Be sure to turn off the power; otherwise, electric shock may result.
- Do not approach or touch any rotating parts (output shaft, etc.) during maintenance or inspection of the unit; loose clothing may become caught in these rotating parts and cause serious injury or death.
- Customers shall not disassemble or modify explosion-proof type motors; otherwise, explosion, ignition, electric shock, or damage to the equipment may result.
- The lead-in condition of an explosion-proof type motor shall conform to the facilities electrical codes, extension regulations and explosion-proofing guide, as well as the maintenance manual; otherwise, explosion, ignition, electric shock, or damage to the equipment may result.

A

CAUTION

- Do not put fingers or foreign objects into the opening of the gearmotor otherwise, electric shock, personal injury, fire, or damage to the equipment may result.
- The gearmotor becomes very hot during operation. Touching the unit with bare hands may result in serious burns.
- Do not touch the terminal when measuring insulation resistance; otherwise, electric shock may result.
- Promptly identify and correct, according to instructions in this manual, any abnormalities observed during operation. Do not operate until abnormality is corrected.
- Do not use damaged gearmotors; otherwise, personal injury, fire, or damage to the equipment may result.
- We can not assume any responsibility for damage or injury resulting from an unauthorized modification by a customer.
- Dispose gearmotor, lubricant as general industrial waste.
- When measuring the insulation resistance of an explosion-proof type motor, confirm that there is no gas, steam, or other explosive substance around the unit in order to prevent, explosion or ignition.
 - The gear section is filled with long-life grease that allows it to operate for extended periods without replenishment. However, overhaul the gear section every 20,000 hours or 3 to 5 years to ensure long service life.
 - Sealing effect of an oil seal will be deteriorated due to natural degradation and wear as its life during long term operation.
 - Life time of an oil seal varies substantially depending on service condition and ambient environment for the reducer.

It is recommendable that oil seal is changed every one to three years as a guide for normal operation. (Under uniform load, room temperature and 10 hours operation per day)

In addition, oil seal and V-ring should be changed with new one when wear and/or rust are found on the sliding surface of it.

As sliding surface is carbon steel, it may get rusted due to rainwater or condensation and damage an oil seal. Therefore periodical rust prevention is required.

· Overhauling the gearmotor or reducer reguires specific skills. Be sure to use a workshop specified by Sumitomo for overhaul.



To ensure proper and continued optimum operation, use Table 11 to perform daily inspections.

Table 11 Daily Inspection

Inspection item	Details of inspection
Electric current	Is the current below the rated current shown on the rating plate ?
Noise	Is there abnormal sound? Is there sudden change in sound?
Vibration	Is there excessive vibration? Does vibration change suddenly?
Surface temperature	Is the surface temperature abnormally high? Does the surface temperature rise suddenly? The temperature rise during operation differs according to the model. When the difference between the temperature of the gear surface and the ambient temperature is approx. 40°C degrees, there will be no problem if there is no fluctuation.
Grease leakage	Does oil or grease leak from the gear section ?
Foundation bolt	Are foundation bolts loose ?
Chain and V-belt	Are chain and V-belt loose ?
Brake OB	Is the brake lining abraded ? After operation for an extended period of time, the brake lining becomes abraded. Check the brake gap occasionally, following instructions in section 9, Brake Inspection / Maintenance (p.40-48).

When any abnormality is found during the daily inspection, take corrective measures according to Section 10, Troubleshooting (pages 50 and 51.) If the abnormality cannot be eliminated, contact our nearest agent, distributor, or sales office.



9. Brake Maintenance

- This section discusses the operation and maintenance of the sumitomo brake. (When using another manufacturer's brake, please refer to their maintenance manual.)
- Refer to Brake operation manual (Cat.No.MM0202E) for FB-01A1, 02A1, 05A1, 1D, 2D, 3D, 5B, 8B,10B1 and 15B1 outdoor type.

DANGER

- Do not handle the unit when cables are live. Be sure to turn off the power; otherwise, electric shock may result.
- When the motor is used for lifting, do not release the brake while a load is lifted, otherwise the load may fall, leading to an accident.
- Do not operate the motor with the brake released by the manual loosening bolt, otherwise the motor may fall or go out of control.
- Turn on and off the power to check the braking operation before starting the motor, otherwise the motor may fall or go out of control.
- Do not allow water or grease to collect on the brake, otherwise the motor may fall or go out
 of control due to a drop in the brake torque.


CAUTION

- After inspection and/or adjustment of the gap, do not operate the motor without replacing the fan cover; otherwise loose clothing may become caught in rotating parts and cause serious injury.
- Replacing the brake lining reguires specific skills. Be sure to use a workshop specified by sumitomo for brake replacement.
 - The mechanical life of the FB brake is 2,000,000 times, but periodically check the brake gap G. After use for an extended period of time, the brake lining will be abraded, making it impossible to release the brake. When the brake is used for more than 2,000,000 times, the motor may fall or go out of control because of the abrasion or breakage of mechanical parts.
 - In the initial operation or right after exchange of the brake lining, specified braking torque might not be outputted. When this happens, under the least loading, turn the power switch on and off to rub the friction sides together.



9-1) Construction and Operation

Figs. 33–42 show the construction of the brake. A spring is used for braking operation (nonexcitation operation type).



No.	Part name
1	Brake restraining bolt
2	Stationary
3	Armature plate
4	Lining with fan
5	Setting bolt
6	Retaning ring
7	Cover
8	Torque spring




Fig.34 SB-004 (water-proof type)

No.	Part name
1	Brake restraining bolt
2	Stationary
3	Armature plate
4	Lining with fan
5	Setting bolt
6	Retaning ring
7	Cover
8	Torque spring







Fig.35 MB-003, 005



6 5 4 3 2 1
/ / \
/ / \
7891

Fig.36 MB-003, 005 (Water-proof type)
87654321
9 10 12 13 14 15 16

Fig.37 FB-01A1, 02A1, 05A1

No.	Part name
1	Brake lining
2	Armature plate
3	Cover
4	Leaf spring
5	Torque spring
6	Stationary
7	Boss
8	Boss setting bolt
9	Brake restraining bolt
10	Fixed plate

No.	Part name
1	Stationary core
2	Spacer
3	Brake lining
4	Assembling bolt
5	Boss
6	Shaft retaining C-ring
7	Cover
8	Fan set bolt
9	Fan
10	Leaf spring
11	Fixed plate
12	Armature plate
13	Spring
14	Electromagnetic coil
15	Ball bearing
16	Motor shaft

FB-01A1 for 3-phase motor 0.1kW does not apply to No.8,9.






Fig.38 FB-1D

No.	Part name
1	Stationary core
2	Release fitting
3	Manual release prevention spacer
4	Brake release bolt
5	Spacer
6	Gap adjusting shim
7	Assembly bolt
8	Brake lining
9	Leaf spring
10	Boss
11	Shaft retaining C-ring
12	Fan set bolt
13	Cover
14	Fan
15	Fixed plate
16	Armature plate
17	Spring
18	Electromagnetic coil
19	Ball bearing
20	Motor shaft





Fig.39 FB-2D

No.	Part name
1	Stationary core
2	Release fitting
3	Manual release prevention spacer
4	Brake release bolt
5	Spacer
6	Gap adjusting shim
7	Assembly bolt
8	Brake lining
9	Leaf spring
10	Boss
11	Shaft retaining C-ring
12	Fan set bolt
13	Cover
14	Fan
15	Fixed plate
16	Armature plate
17	Spring
18	Electromagnetic coil
19	Ball bearing
20	Motor shaft





2 Release fitting 3 Stud bolt 4 Adjusting washer 5 Manual release prevention spacer 6 Brake release bolt 7 Spring washer 8 Gap adjusting nut 9 Brake lining 10 Boss Shaft retaining C-ring 11 Cover 12 13 Spring pin 14 Fan 15 Leaf spring 16 Fixed plate 17 Armature core 18 Spring Electromagnetic coil 19 20 Ball bearing 21 Motor shaft

Part name

Stationary core

No.

Fig.40 FB-3D




Fig.41 FB-5B, 8B

No.	Part name
1	Stationary core
2	Release fitting
3	Stud bolt
4	Adjusting washer
5	Manual release prevention spacer
6	Brake release bolt
7	Spring washer
8	Gap adjusting nut
9	Brake lining
10	Boss
11	Shaft retaining C-ring
12	Cover
13	Spring pin
14	Fan
15	Leaf spring
16	Fixed plate
17	Armature core
18	Spring
19	Electromagnetic coil
20	Ball bearing
21	Motor shaft






Fig.42 FB-10B1, 15B1


No.	Part name
1	Stationary core
2	Release fitting
3	Stud bolt
4	Adjusting washer
5	Manual release prevention spacer
6	Brake release bolt
7	Spring washer
8	Gap adjusting nut
9	Brake lining
10	Boss
11	Shaft retaining C-ring
12	Cover
13	Fan set bolt
14	Fan
15	Leaf spring
16	Fixed plate
17	Armature core
18	Spring
19	Electromagnetic coil
20	Ball bearing
21	Motor shaft



9-2) Manual Release Operation of Brake (FB-1D-15B1, FB-01A1-05A1 are options.)

To manually release the brake without turning on the power, operate the brake release device as follows:

- (1) Remove the brake release bolts arranged diagonal to each other, and remove the spacer. Then screw in the bolts with a hexagon wrench, and the brake will be released. Be careful not to turn the brake release bolts excessively. (Check to see if the brake is released, while turning the brake release bolts.) (See Fig. 43.)
- (2) To return to the original state after releasing the bolts, re-install the spacer, which was removed in step (1), to the original position for safety. (See Fig.44.)



9-3) Gap Inspection

When the brake is used for a long time, the brake lining becomes abraded and the brake cannot be released. Periodically check the gap G as follows:

- (1) Remove the cover.
- (2) Insert the feeler gauge between the stationary and armature cores to measure the gap. When the gap is near the limit shown in Table 12, adjustment is necessary. Measure three points along the circumference. (Gap of MB-003, 005 can not be adjusted. The minimum thickness of the gap adjusting shim for FB-1D-3D is 0.2-0.25mm.)

Table 12 Brake Gap

Type of brake	Gap G (mm)			
туре от Бтаке	Specification (Initial value)	Limit		
SB-004	0.15–0.25	0.4		
MB-003 MB-005	0.05-0.25	0.35		
FB-01A1 FB-02A1 FB-05A1	0.2-0.35	0.5		
FB–1D FB–2D	0.3–0.4	0.6		
FB-3D		0.7		
FB-5B FB-8B	0.4–0.5	1.0		
FB-10B1 FB-15B1	0.4–0.5	1.2		



9-4) Gap Adjustment

When the gap nears the limit shown in Table 12 on page 39, follow these steps to, adjust the gap. (Gap of MB-003, 005 can not be adjusted.)

[SB-004] (See Fig.33, 34 on page 41)

- (1) Remove cover (7).
- (2) Slightly loosen set bolt 5. (locking agent was done)
- (3) Adjast gap G by inserting the feeler gauge between the stationary core ② and armature core ③.
- (4) Apply a locking agent to set bolt (5) and fixed lining fan.
- (5) Install cover ①. (For water proof-type. Please check no crack on O-ring. If any, please exchange.)

[FB-01A1, 02A1, 05A1] (See Fig.37 on page 42)

- Remove cover 7.
- (2) Slightly loosen assembly bolt ④, and turn fixed plate ① counterclockwise to the maximum. Then tighten the assembly bolt. After tightening, measure the gap G, and confirm that it is between the specification and limit. (After this operation, the gap will decrease by approx. 0.3mm.)
- (3) After adjusting the gap, check the brake's performance by turning the system power on and off a few times.
- (4) Install cover 7.

[FB-1D] (See Fig.38 on page 43)

- (1) Remove assemble bolt 4 and manual release prevention spacer 3.
- (2) Remove cover 13.
- (3) Remove fan set bolt 12, and remove fan 14.
- (4) Loosen assembly bolt ①, and remove spacer ⑤, gap adjusting shim ⑥, assembly bolt ①, and fixed plate ⑤ together as a set. Be careful not to remove assembly bolt ② alone; otherwise, gap adjusting shim ⑥ will drop.
- (5) Gap adjusting shim (§) is approx. 0.2–0.25mm thick. Reduce the number of shims according to the amount of abrasion, and reassemble spacer (§), gap adjusting shim (§), assembly bolt (⑦), and fixed plate (§) together as a set.
- (6) Check the gap G, and if it is substantially different from the specification, readjust the shim.
- (7) After adjusting the gap, check the brakes performance by turning the system power on and off a few times.
- (8) Install fan (4), fan set bolt (2), and cover (3). Apply a locking agent to the fan set bolt at that time. Finally, install release bolt (4) and spacer (5).
 - Then install assemble bolt 4 and manual release prevention spacer 3.



[FB-2D] (See Fig.39 on page 43)

- (1) Remove assemble bolt 4 and manual release prevention spacer 3.
- (2) Remove cover (13).
- (3) Remove fan set bolt 12, and remove fan 14.
- (4) Loosen assembly bolt $\overline{ }$, and remove spacer $\overline{ }$, gap adjusting shim $\overline{ }$ e, assembly bolt $\overline{ }$, and fixed plate $\overline{ }$ together as a set. Be careful not to remove assembly bolt $\overline{ }$ alone; otherwise, gap adjusting shim $\overline{ }$ will drop.
- (5) Gap adjusting shim 6 is approx. 0.2–0.25mm thick. Reduce the number of shims according to the amount of abrasion, and reassemble spacer 5, gap adjusting shim 6, assembly bolt 7, and fixed plate 5 together as a set.
- (6) Check the gap G, and if it is substantially different from the specification, readjust the shim.
- (7) After adjusting the gap, check the brakes performance by turning the system power on and off a few times.
- (8) Install fan (4), fan set bolt (2), and cover (3). Apply a locking agent to the fan set bolt at that time. Finally, install release bolt (4) and spacer (5).

Then install assemble bolt @ and manual release prevention spacer ③.

[FB-3D] (See Fig.40 on page 44)

- (1) Remove assemble bolt 4 and manual release prevention spacer 3.
- (2) Remove cover 13.
- (3) Remove fan set bolt ①, and remove fan ④.
- (4) Loosen assembly bolt $\overline{ }$, and remove spacer $\overline{ }$, gap adjusting shim $\overline{ }$ e, assembly bolt $\overline{ }$, and fixed plate $\overline{ }$ together as a set. Be careful not to remove assembly bolt $\overline{ }$ alone; otherwise, gap adjusting shim $\overline{ }$ will drop.
- (5) Gap adjusting shim ⑥ is approx. 0.2–0.25mm thick. Reduce the number of shims according to the amount of abrasion, and reassemble spacer ⑤, gap adjusting shim ⑥, assembly bolt ⑦, and fixed plate ⑤ together as a set.
- (6) Check the gap G, and if it is substantially different from the specification, readjust the shim.
- (7) After adjusting the gap, check the brakes performance by turning the system power on and off a few times.
- (8) Install fan (4), fan set bolt (2), and cover (3). Apply a locking agent to the fan set bolt at that time. Finally, install release bolt (4) and spacer (5).

Then install assemble bolt 4 and manual release prevention spacer 3.



[FB-5B, 8B, 10B1 and 15B1] (See Fig.38 on page 41, Fig. 42 on page 45)

- (1) Remove assemble bolt (6) and manual release prevention spacer (5).
- (2) Remove cover 12.
- (3) Insert the feeler gauge between stationary core ① and armature core ①, and turn clockwise the gap adjusting nut ⑧ attached to the end of stud bolt ③. When adjustment is impossible due to an excessively large gap, reduce the number of adjusting washers ④. Alternately turn the adjusting nuts, arranged at three locations around the circumference, so that all three gaps will be as specified in Table 12.
- (4) After adjusting the gap, check the brake's performance by turning the system power on and off a few times.
- (5) Install cover 12.

Then install assemble bolt (6) and manual release prevention spacer (5).

9-5) Brake Lining Replacement

When the thickness of the brake lining has reached the limit shown in Table 13 (When the brake gap has reached the limit shown in Table 12 on page 46 for MB-003, 005. When the brake gap has reached the limit shown in Table 12 on page 46 after gap adjustment in for FB-01A1, 02A1, 05A1.), Contact Sumitomo for brake lining replacement.

Brake Lining Initial Thickness Thickness Limit Brake Type Dimension to (mm) to (mm) SB-004 5.0 46 MB-003 7.0 MB-005 FB-01A1 FB-02A1 7.0 FB-05A1 FB-1D 7.0 6.0 FB-2D 8.8 7.8 FB-3D 9.0 8.0 FB-5B, 8B 10 6.0 FB-10B1, 15B1 11 7.0

Table 13 Brake Lining Dimension

9-6) Change of V-ring and waterproof seal (in a case of outdoor type)

Inspect a V-ring and waterproof seal every three years as a guide because waterproof effect is deteriorated due to aging degradation, and etc.

Consult with the nearest certified service shop when something defective on waterproof is found by inspection.

In addition, V-ring should be changed with new one when wear and/or rust are found on the sliding surfaces of it.

As sliding surface is carbon steel, it may get rusted due to rainwater or condensation and damage an oil seal and V-ring. Therefore periodical rust prevention is required.



10. Troubleshooting

· If any abnormality is found in the gearmotor, refer to Table 14 below and take appropriate measures as soon as possible. If the abnormality cannot be eliminated, contact our nearest agent, dealer or sales office.

Table 14 Troubleshooting

		Type of Trouble	Cause	Remedy	
			Power failure	Contact the power supply company.	
			Defective electric circuit	Check the defective portion of electric circuit.	
			Fusing	Replace the fuse.	
			Safety device at work	Eliminate a cause of incorrect safety device actuation.	
			Locking of the load	Check and investigate the load and the safety device.	
			Poor contact of swich	Adjust the contact.	
			Disconnection of motor stator wiring		
			Broken bearing	Consult with the certified service shop.	
The motor does not run in the unloaded condition.			Defective cover switch (0.1–0.4kW single-phase motor)	Consult with the certified service shop.	
			Broken capacitor(single-phase motor)	Consult with the certified service shop.	
			Three-phase motor acting as single-phase motor (3-phase motor)	Check the power sorce using a voltmeter. Repair or replace the motor, transformer coils, contactors and fuses.	
			Brake :Rust on friction surface	Consult with the certified service shop.	
			Brake :Poor gap adjustment	Fine adjustment of brake gap. (P. 46–49)	
The motor works but the output shaft does not work.			Defective gear drives due to overloading etc.	Consult with the certified service sho	
		Switch is overheated.	Insufficient switch capacity	Replace the switch with one having the specified capacity.	
Ħ	-		Overloading	Reduce the load to the specified level.	
3, b			Insufficient fuse capacity	Replace the fuse with one having a specified capacity.	
dij		Fuse is cut.	Overloading	Reduce the load to the specified level.	
ut loa	When loaded	r doe is out.	Defective governor switch (0.1—0.4kW single-phase motor)	Consult with the certified service shop.	
유	loa	Rotating speed does not increase and overheated.	Voltage drop	Consult with the power supply company.	
N N	en		Overloading	Reduce the load to the specified level.	
The output shaft rotates without loading, but	Wh		Drop in capacitance (single-phase motor)	Consult with the certified service shop.	
ᄩ			Short circuit of motor stator winding	Consult with the certified service shop.	
Sh		Motor stops.	The key is not set on the shaft	Set the key.	
bt			Burned bearing	Consult with the certified service shop.	
ont			Defective adjustment of the safety device	Adjust the safety device.	
The motor rotates reversely.		motor rotates reversely.	Wrong connection	Connect correctly.	
Disconnected fuse.		connected fuse	Short-circuit of the lead wire	Consult with the certified service shop	
			Poor connection of the motor with the starter	Connect firmly.	
Excessive rise in temperature			Overloading	Reduce the load to a specified level.	
			Increased or decreased voltage	Consult with the power supply compa	
			Defective governor switch (in 0.1–0.4kW single-phase motor)	Consult with the certified service shop.	
		temperature	Deteriorated condenser capacity (single-phase motor)	Consult with the certified service shop.	
			Ambient temperature is too high.	Improve the ventilation method.	
			Failure due to overloading to shaft and gear	Consult with the certified service shop.	



Table 14 Troubleshooting

		roubleshooting	Cause	Remedy	
Type of Trouble		rpe or mounte		Remedy	
	Ooze seal.	e of grease from an oil	Ooze of lubricating grease from an oil seal at an early stage of operation.	Wipe up grease or replace an o seal when grease leakage cann be protected.	
Great Se outp		ase leakage from the ut section	Damaged oil seal.	Consult with the certified service shop.	
Gre		ase leakage from the ng seam	Slacked bolts.	Tighten the bolts or consult with the certified service shop.	
			Damaged gear.	Consult with the certified service shop.	
Abnormal noise or excessive vibration			Distortion of the housing due to rough bed surface.	Flatten the bed surface or adjust the bed with the liner.	
			Resonance resulting from insufficient rigidity of the bed.	Improve rigidity of the bed by reinforcement.	
			Misalignment of connecting shafts.	Realign or use flexible coupling.	
			Vibration transferred from the connected machine.	Detect vibration sources by running the gearmotor independently.	
			Foreign substances inside the motor.	Eliminate the foreign substances.	
			Damaged bearing.	Consult with the certified service shop.	
			Improper brake gap adjustment.	Adjust the brake gap. (Refer to page 46–49)	
			Worn brake lining.	Replace the brake lining. (Refer to page 49)	
Abnoi	Abnormal noise in the motor		Burned magnetic coil in the brake assembly.	Consult with the certified service shop.	
			Failure of the rectifier	Replace the rectifier.	
			Disengagement or failure of leaf spring in the brake boss.	Consult with the certified service shop.	
			Defective governor switch (0.1- 0.4kW single-phase motor)	Consult with the certified service shop.	
		Brake does not work.	Releasing bolt not returned to the original position.	Return the bolt to the original position and readjust the gap.	
king		The brake slips. Braking response is slow.	A fast braking circuit is not working.	Shift to the fast braking action (Refer to page 27–34)	
ctive bra	uc		Foreign substances or oil are adhered to the brake lining.	Consult with the certified service shop.	
Ineffective braking function	function		Worn brake lining.	Adjust the brake gap or consult with the certified service shop.	
	all		Uneven brake gap.	Adjust the brake gap.	
	미		Overloading.	Reduce the load or apply a larger brake frame.	
			Insufficient recovery of the releasing bolt.	Reset the releasing bolt to the original position and readjust the gap.	
		Shut-off due to	Sudden acceleration / deceleration	Make the acceleration / deceleration time longer.	
nverter tripping	overcurrent	Sudden change in load	Decrease the load.		
		Grounding overcurrent	Grounding on the output side	Make correction to eliminate grounding	
		DC overcurrent	Short - circuiting on the output side	Make correction to eliminate short -circuiting. Check cables.	
<u> </u>	3	Shut-off due to regenerative overvoltage	Sudden deceleration	Make the deceleration time longer. Reduce the braking frequency.	
		Thermal relay operation	Overloading	Decrease the load to the specified value.	



11. Construction Drawings




Fig.44 RNFM0025-03L-240




Fig.45 RNYM0025-03-240

No.	Part name	No.	Part name	No.	Part name
1	Hypoid gear	7	Gear	13	Rotor core
2	Output shaft	8	Pinion shaft	14	Rotor conductor short circuit ring
3	Oil seal	9	Gear	15	Stator windings
4	Casing	10	Pinion shaft	16	End bracket
5	Cover	11	Hypoid pinion shaft	17	Bearing metal
6	Seal cap	12	Stationary core	18	Bearing metal






Fig.46 RNFM1-50R-120




Fig.47 RNYM1-1530-120

No.	Part name	No.	Part name	No.	Part name
1	Hypoid gear	8	Gear	15	Rotor conductor short circuit ring
2	Output shaft	9	Pinion shaft	16	Fan
3	Oil seal	10	Hypoid pinion shaft	17	Fan cover
4	Case (1)	11	Motor frame	18	End bracket
5	Case (2)	12	Stationary core	19	Bearing metal
6	Gear	13	Rotor core	20	Bearing metal
7	Pinion shaft	14	Stator windings	21	Cyclo flange bracket



12. Warranty

The scope of our warranty for our products is limited to the range of our manufacture. Warranty (period and contents)

Warranty Period	The warranty period for the Products shall be 18 months after the commencement of delivery or 18 months after the shipment of the Products from the seller,s works or 12 months from the Products coming into operation, whether comes first.
Warranty Condition	In case that any problems, troubles or damages on the Products arise due to the defects in the Products during the above "Warranty Period", although the Products are appropriately and properly installed in, connected or combined to the equipment or machines, or maintained in accordance with the maintenance manual and are properly operated under the conditions as described in the catalogue or otherwise as agreed upon in writing between the Seller and the Buyer or its customers, the Seller will Provide, at its sole discretion, appropriate repair or replacement on the Products free of charge, except as stipulated in the "Exception for Warranty" as described below. However, in the event that the Products is installed in, connected or combined to or integrated into the equipment or machines, the Seller shall not reimburse the costs for removal or re-installation of the Products or other incidental costs related thereto and any lost opportunity, loss of profit or any other incidental or consequential losses or damages incurred by the Buyer or its customers.
Exception for Warranty	Notwithstanding the above warranty, the warranty as set forth herein shall not be applied to the problems, troubles or damages on the Products which are caused by: 1. installations, connections, combinations or integration of the Products in or to the other equipment or machines, which are rendered by any person or entity other than the Seller, 2. the insufficient maintenance or improper operation by the Buyer or its customers, such that the Product is not appropriately maintained in accordance with the maintenance manual provided or designated by the Seller, 3. the improper use or operation of the Products by the Buyer or its customers which are not informed to the Seller, including, without limitation, the Buyer's or its customers' operation of the Products not in conformity with the specifications, or use of the lubrication oil in the Products which is not recommended by the Seller, 4. troubles, problems or damages on any equipment or machines in or to which the Products are installed, connected or combined or installed, or any specifications particular to the Buyer or its customers, or 5. any changes, modifications, improvements or alterations on the Products or those functions which are rendered on the Products by any person or entity other than the Seller, 6. any parts in the Products which are supplied or designated by the Buyer or its customers, 7. earthquake, fire, flood, sea-breeze, gas, thunder, acts of God or any other reasons beyond the control of the Seller, 8. waste, exhaustion, normal tear or wear, or deterioration on the parts of the Products, such as bearing, oil-seal. 9. any other troubles, problems or damages on the Products which are not attributable to the Seller.

Worldwide Locations

U.S.A

Sumitomo Machinery Corporation of America

4200 Holland Blvd. Chesapeake, VA 23323, U.S.A. TEL (1)757-485-3355 FAX (1)757-485-7490

Canada

SM Cyclo of Canada, Ltd. (SMC)

1453 Cornwall Road, Oakville, Canada ON L6J 7T5 TEL (1)905-469-1050 FAX (1)905-469-1055

SM Cyclo de Mexico, S.A. de C.V. (SMME) Av. Desarrollo 541, Col. Finsa, Guadalupe, Nuevo León, México, CP67132

TEL (52)81-8144-5130 FAX (52)81-8144-5130

Brazil

Sumitomo Industrias Pesadas do Brasil Ltda. (SHIB)

Rodovia do Acucar (SP-075) Km 26 Itu, Sao Paulo, Brasil TEL (55)11-4886-1000 FAX (55)11-4886-1000

Chile

SM-Cyclo de Chile Ltda. (SMCH)

San Pablo 3507, Quinta Normal, Santiago, Chile TEL (56)2-892-7000 FAX (56)2-892-7001

Argentina

SM-Cyclo de Argentina S.A. (SMAR)

Ing. Delpini, 2236 Area de Promocion el Triangulo, Partido Malvinas Argentinas Grand Bourg. Buenos Aires, Argentina B1615KGB TEL(54)3327-45-4095 FAX (54)3327-45-4099

Guatemala

SM Cyclo de Guatemala Ensambladora, Ltda.

Parque Industrial Unisur, 0 Calle B 19-50 Zona 3. Bodega D-1 Delta Bárcenas en Villa Nueva, Guatemala TEL (502)6648-0500 FAX (502)6631-9171

SM Cyclo Colombia, S.A.S. (SMCO)

Carrera 11, No.93A-53, Office 203, Bogotá, Colombia TEL (57)1_3000673

Germany

Sumitomo (SHI) Cyclo Drive Germany GmbH

(SCG) Cyclostraße 92, 85229 Markt Indersdorf, Germany TEL (49)8136-66-0 FAX (49)8136-5771

Austria

Sumitomo (SHI) Cyclo Drive Germany GmbH (SCG)

SCG Branch Austria Office

Gruentalerstraße 30A, 4020 Linz, Austria TEL (43)732-330958 FAX (43)732-331978

Belgium

Sumitomo (SHI) Cyclo Drive Germany GmbH (SCG)

SCG Branch Benelux Office

Heikneuterlaan 23, 3010 Kessel-Lo, Leuven, Belgium TEL (32)16-60-83-11 FAX (32)16-60-16-39

France

SM-Cyclo France SAS (SMFR)

8 Avenue Christian Doppler, 77700 Serris, France FAX (33)164171718 TEL (33)164171717

Italy

SM-Cyclo Italy Sri (SMIT)

Via dell' Artigianato 23, 20010 Cornaredo (MI), Italy TEL (39)293-481101 FAX (39)293-481103

SM-Cyclo Iberia, S.L.U. (SMIB)

C/Landabarri No. 3, 6° B, 48940 Leioa, Vizcaya, Spain TEL (34)9448-05389 FAX (34)9448-01550

Sweden

SM-Cyclo Scandinavia AB (SMSC)

Industrigatan 21B, 234 35 Lomma, Sweden TEL (46)40220030

United Kingdom

SM-Cyclo UK Ltd. (SMUK)

Unit 29, Bergen Way, Sutton Fields Industrial Estate, Kingston upon Hull, HU7 OYQ, East Yorkshire, United Kingdom

TEL (44)1482-790340 FAX (44)1482-790321

Turkey

SM Cyclo Turkey Güç Aktarım Sis. Tic. Ltd. Sti. (SMTR)

Büvükdere Cavırbası Cd. Dede Yusuf Sk. No: 11. 34453 Sariver Istanbul, Turkey TEL (90)216-384-4482 FAX (90)216-384-4482

Sumitomo (SHI) Cyclo Drive China, Ltd. (SCT)

11F, SMEG Plaza, No. 1386 Hongqiao Road, Changning District, Shanghai, China (P.C. 200336) TEL (86)21-3462-7877 FAX (86)21-3462-7922

Hong Kong

SM-Cyclo of Hong Kong Co., Ltd. (SMHK) Rm 1301, CEO Tower, 77 Wing Hong Street, Cheung Sha Wan, Kowloon, Hong Kong TEL (852)2460-1881 FAX (852)2460-1882

Korea

Sumitomo (SHI) Cyclo Drive Korea, Ltd. (SCK)

Royal Bldg. 9F Rm. 913, 5 Danju-Dong, Chongro-Ku, Seoul, Korea 110-721 TEL (82)2-730-0151 FAX (82)2-730-0156

Taiwan

Tatung SM-Cyclo Co., Ltd. (TSC)

22 Chungshan N. Road 3rd., Sec. Taipei, Taiwan 104, R.O.C.

TEL (886)2-2595-7275 FAX (886)2-2595-5594

Singapore

Sumitomo (SHI) Cyclo Drive Asia Pacific Pte. Ltd. (SCA)

15 Kwong Min Road, Singapore 628718 TEL (65)6591-7800 FAX (65)6863-4238

Philippines

Sumitomo (SHI) Cyclo Drive Asia Pacific Pte. Ltd. (SCA)

Philippines Branch Office

B2B Granville Industrial Complex, Carmona. Cavite 4116, Philippines

TEL (63)2-8584-4921

FAX (63)02-584-4922 TEL (63)046-430-3592

TEL (63)046-231-0570

SM-Cyclo (Vietnam) Co., Ltd. (SMVN)

Factory 2B, Lot K1-2-5, Road No. 2-3-5A, Le Minh Xuan Industrial Park, Rinh Chanh Dist HCMC Vietnam

TEL (84)28-3766-3709 FAX (84)28-3766-3710

Malaysia

SM-Cyclo (Malaysia) Sdn. Bhd. (SMMA)

No.7C, Jalan Anggerik Mokara 31/56, Kota Kemuning, Seksyen 31, 40460 Shah Alam, Selangor Darul Ehsan, Malaysia

TEL (60)3-5121-0455 FAX (60)3-5121-0578

Indonesia

PT. SM-Cyclo Indonesia (SMID)

Jalan Sungkai Blok F 25 No. 09 K, Delta Silicon 3, Lippo Cikarang, Bekasi 17530, Indonesia TEL (62)21-2961-2100 FAX (62)21-2961-2211

SM-Cyclo (Thailand) Co., Ltd. (SMTH) 1 Empire Tower, Unit 2103-4, 21st Floor, South Sathorn

Road, Yannawa, Sathorn, Bangkok 10120, Thailand TEL (66)2670-0998 FAX (66)2670-0999

Australia

Sumitomo (SHI) Hansen Australia Pty. Ltd. (SHAU)

181 Power St. Glendenning, NSW 2761, Australia TEL (61)2-9208-3000 FAX (61)2-9208-3050

Sumi-Cyclo Drive India Private Limited (SMIN)

Survey No. 130, Hissa No. 02, Jeevan Nagar, Off Mumbai-Bangalore Bypass, Tathawade, Pune - 411033, India TEL (91)20-6674-2900 FAX (91)20-6674-2901

Japan

Sumitomo Heavy Industries, Ltd. (SHI) ThinkPark Tower, 1-1 Osaki 2-chome, Shinagawa-ku,

Tokyo 141-6025, Japan TEL (81)3-6737-2511 FAX (81)3-6866-5160

Specifications, dimensions, and other items are subject to change without prior notice.

